

STANDARD

SELECT BRAKE BRAKE SHOE KIT

MADE IN THE USA
ASSEMBLED IN CANADA

#GBEK4707QSBA23

\$44.99 /each

#GBEK4709E2SBA23

\$46.99 /each



*Image is a representation only
*Hardware kit INCLUDED

ASSEMBLED
IN CANADA



PREMIUM

SELECT BRAKE BRAKE SHOE KIT

MADE IN THE USA
ASSEMBLED IN CANADA

#GBEK4707QSBP23

\$48.99 /each

#GBEK4709E2SBP23

\$53.99 /each



*Image is a representation only
*Hardware kit INCLUDED

ASSEMBLED
IN CANADA



\$ 119.95
each

Gorilla Brake ADB Pad Cross-Reference

Gorilla Air Disc Brakes

#GBADP1369

GBC Number	Make	Application	FMSI	Bendix/Knorr	Meritor	OEM Numbers	Caliper
GBADP1369	Knorr-Bremse	Freightliner, KW, IHC, Mack, Volvo, Peterbilt, Hendrickson	8479D1369		K070796 K109113		ADB22X, SK7

PIGGY BACK BRAKE CHAMBER

#GBSB3030PBK

3 YEAR WARRANTY

\$39.99

/each



LONG STROKE CHAMBER

#GBSB3030LS

\$48.99

/each

